



Tech Note TS0001

TalkSwitch – Remote Voicemail Access

There are two ways to remotely access voicemail on a TalkSwitch system:

- 1) Call into any number that is answered by an automated attendant. When you get the greeting, press ** + mailbox number. NOTE: The system must be able to distinguish that the * key was pressed twice, so allow for a gap between them.
- 2) For voicemail boxes with their own external or DID numbers, dial the number, and when the voicemail greeting begins, press 8.